

Spar parts for PVP 252 Motor

[PDF](#)

1	2	3	4	6	7	8	9	10	11	12	13			
-------------------	-------------------	-------------------	-------------------	-------------------	-------------------	-------------------	-------------------	--------------------	--------------------	--------------------	--------------------	--	--	--




346 Oil plug with glass



348 T-part for water with treed for temp probe



O-ring between cylinder and socket no. 772 (45.69x2.62)



O-ring for exhaust pipe (FPM) no. 770 (42.52x2.62)

354 Exhaust socket 2




356 Bracket for exhaust




357 Steel ring for exhaust




366 Exhaust valve slide single step 2



370 Compression spring 4.6x32 8



374 Compression spring 13.2x0.8x52.5



375 Compression spring 13.3x0.9x48.5



379 Rubber bellow new type



382 Bushing between 379 and 380



O-ring under this 759 (32.99x2.62)



O-ring outside 742 (18.77x1.78)




380 Valve rod housing 2




381 Bushing 6/12x42 2




384 Valve piston




385 Spring for 379



389 Piston pin 15x45



390 Needle bearing 15/19x19.6 2



392 Piston ring 54x1, for 394, 395, and 396



3962 Piston ring 54x0.8, for piston 3965 and 3975